

LED FLASHLIGHT US-15G, 10W, 1500lm

Ideal as main light.

Thanks to a cooling radiator on the torch's housing, the product doesn't overheat on the surface. Its low weight without the batteries (4 x R14) makes it perfect for traveling by air.

- Light source: LED "Cree"-XML T6, light color: white
- LED's lifespan: about 100 000h
- Power: 10W, 1500 lm
- Beam angle: 10 degrees
- Color temperature: 6000 K - 7000 K
- Power supply: 4 x R14
- Control of light's power: 100%, 50%
- Material: anodized aluminum
- Head: lens made of ultra clear, tempered glass and aluminum reflector keeping ideal angle of 10°
- Water-resistance: 200 m (IP 68)
- Working time: about 2,5 h with 100% power (total time for switching off 8h)
- Size: 80 mm x 48 mm (head), 33 mm x 244mm (body)
- Weight: 780 g (without batteries) with Goodman handle

CAUTION!!!

THIS FLASHLIGHT IS INTENDED TO WORK ONLY WITH AAA BATTERIES 1,5V OR RECHARGEABLE BATTERIES WITH NOMINAL VOLTAGE OF 1,2V. USING THE FLASHLIGHT WITH RECHARGEABLE BATTERIES WITH NOMINAL VOLTAGE OF 1,5V MAY RESULT IN DAMAGING THE LED OR ITS ELECTRONICS, WHICH IS NOT COVERED BY THE WARRANTY.

Assembly of Goodman handle

A Goodman handle is included with the flashlight and it should be self-assembled on the torch's head.



Battery replacement

Remove the top cap (part of the torch with the on-switch) in the counter-clockwise direction until the battery compartment is open. Insert 4 R14 batteries with “+” to the top of the cap. Tighten the top cap in the clockwise direction.

DO NOT USE ANY TOOLS FOR TIGHTENING THE CASING

Usage instructions

Make sure that the casing is not over tightened as this could result in damage to the O-rings or their pre-mature wear.

To turn on the light: push the switch, which is placed on the top of the casing once, which will result in turning the light on with 100% power. If you push the switch once again, the light will function with 50% power.

To turn the light off: Depends on the mode. Push the switch once or twice.

Maintenance

After each use, the flashlight should be rinsed with fresh water and allowed to dry before storing. Silicone should be used for greasing the O-rings. Thorough rinsing with fresh water is especially important after use in chlorinated water (for example in the swimming pool), because of the detrimental effects that the chemicals (acids and chlorine) may have on the different materials used in the flashlight. If the O-rings are too loose, they should be replaced. The light should be stored in a cool, dry location away from direct sunlight and any substances that could deteriorate rubber components.

If the light does not light or appear dim, replace used batteries with the completely new ones. Don't mix old and new batteries.

Warranty

This product is covered with 2-year warranty from the date of purchase and it is valid only if it was purchased from the authorized Scubatech distributor. This warranty does not cover damage to the product resulting from improper use, improper maintenance, unauthorized repair or use in chlorinated water without special protection.

CAUTION

1. Do not throw used or unwanted electrical equipment away to dustbin. Such equipment can be left in the shop while we buy the new product. We should only remember that the left device should be of the same quantity and kind.
2. A visible sign showing crossed dustbin means that the device mustn't be thrown away with the rest of garbage but it must be disposed to the place collecting electrical equipment.
3. Segregate e-waste by disposing them to designated garbage containers.
4. Proper utilizing of devices helps in protecting the environment and other people's health. More information on recycling can be obtained in city hall or waste disposal company.

